



# 195003

EMERGENCY SHOWERS AND EYEWASHES - SHOWERS AND EYEWASH ACCESSORIES

## Shower test



*Essential for flow control of the Emergency Shower. Made of plasticized PVC. The operation of the Emergency Showers and Eyewashes should be verified at least ONCE a week in order to guarantee the water supply and to prevent the proliferation of bacteria.*