



# 194900

EMERGENCY SHOWERS AND EYEWASHES - SHOWERS AND EYEWASH ACCESSORIES

Platform to activate Shower (Mod. 1120 4220 4230 4250 4260)



*Accessory to activate the shower by platform, and close the shower by lever.*